

<p>{tab=???????? ??????????}</p> <table border="0" cellspacing="10" cellpadding="0" style="width: 615px; background-color: #ffffff;"> <tr> <td valign="top"> <p style="font-family: arial; font-size: 12px;"><span style="font-family: tahoma, arial, helvetica, sans-serif; font-size: small;"></span></p> </td> <td> <p style="font-family: arial, helvetica, sans-serif; font-size: 10pt; line-height: 21px; color: #777777;">?? module <strong>BF4FXS</strong> ??? ?? module 4 ??? FXS ??? ?? Gateways ??? ?? ????? berofix.<br />? ??????? BF4FXS ?????????????????? ??? ?????? ??? ?????? ?????????????????? ??? ?????????? ?????????? ?????????? ?????? FXS ??? ?????? ?????????? ??????????, ??? ??? ??????. ?? Module 4 ??? FXS ??? ?????? ?????? ?????? ?????? ??? ?????????? ?? ??? ??? ?????? berofix, ?????? ??? Gateways.</p> <p style="font-family: arial, helvetica, sans-serif; font-size: 10pt; line-height: 21px; color: #777777;"><strong>?????????:</strong> ?? module BF4FXS ?????? ?? ?????????????? ??? ?? baseboard berofix ?? ??? ?????? ?????? ??????:<br />- Berofix PCI ?????? ?? ?????? ?????? ?????? 1,9<br />- Berofix PCle ?????? ?? ?????? ?????? ?????? 1,2<br />- ?erofixGateway ?? ?????? ?????? ?????? ?????? 2,2</p> </td> </tr> </table> <p>{tab=?????????}</p> <table border="0" cellspacing="10" cellpadding="0" style="width: 615px; background-color: #ffffff;"> <tr> <td align="center" style="width: 150px;"> <p style="font-family: arial; font-size: 12px;"><strong></strong></p> </td> <td align="center" style="width: 150px;"></td> <td align="center"></td> </tr> <p>{tab=?????????}</p> <table border="0" cellspacing="10" cellpadding="0" style="width: 615px; background-color: #ffffff;"> <tr> <td style="font-family: arial, helvetica, sans-serif; font-size: 10pt; color: #777777;"> <p style="font-family: arial; font-size: 12px;"><strong>?????????:</strong></p> <ul> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; margin-top: 0px; margin-right: 0px; margin-bottom: 0px; border-width: 0px;">supports 0V to -94.5V</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">FXS supports 3-5 REN (depending on line length)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">FXS has Current feed 20-41mA</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">FXS Ringing Frequency, Amplitude, Waveshape and Cadences programmable <br />(by Country Setting)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">?????????: 105 x 46 x 9 mm</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">?????: < 40g</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">Operating Temperature: 0-70°C</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">CE compliance</li> </ul> <span style="text-align: left; color: #bb0000;"><span style="color: #be4048;">? <a target="\_blank" href="images/stories/PDFs/Datasheet\_Modules.pdf">Datasheet moduls</a></span></span></td> </tr> </table> <p>{tab= Accessories}</p> <table

border="0" cellspacing="10" cellpadding="0" style="width: 615px;"> <tr> <td> <p style="font-family: arial; font-size: 12px;"><strong>Accessories</strong></p> <ul style="font-family: arial, helvetica, sans-serif; font-size: 10pt; color: #777777;"> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; margin-top: 0px; margin-right: 0px; margin-bottom: 0px; border-width: 0px;">BFBridge (to use all 4 RJ45 slots on a Baseboard with one bf4S0, bf4FXS, bf4FXO, bf2S02FXS)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">BFTAdapters (to connect 2 BRI or analog Lines on one RJ45 of the berofix)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">BFPCM (PCM Cable to interconnect berofix Baseboards)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">BFE1Cross, (1.8m E1/T1 "cross-over" cable)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">BF19bracket (19 inch rack mount bracket for berofix Boxes)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">BFANTS (small 7 cm stock antenna for BF2GSM modules)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">BFANTL (2m cable antenna with magnetic foot for BF2GSM modules)</li> <li style="padding-top: 0px; padding-right: 0px; padding-bottom: 0px; border-style: initial; border-color: initial; border-width: 0px; margin: 0px;">BFFXXCable (RJ45 to RJ11 cable to use with berofix analog modules)</li> </ul> </td> </tr> </table>

<p>{/tabs}</p>